




Samsung Galaxy Tab Pro 10.1 Front Facing Camera Replacement

Replace the front facing camera on the Samsung Galaxy Tab Pro 10.1.

Written By: Stephen Yeung



INTRODUCTION


This guide will show how to replace the front facing camera on the Samsung Galaxy Tab Pro 10.1.




TOOLS:

- [Metal Spudger Set](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Universal 4 mm Driver Handle](#) (1)
 - [Tweezers](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-




Step 1 — Rear Panel



 Be gentle, the front panel is connected to sensitive wiring that may snap if too much pressure is applied.

- Insert a plastic opening tool into the crevice between the screen and the side of the tablet.
- Go around the entire crevice with the plastic opening tool.
- Set aside the separated front and rear panels of the device.

Step 2 — Front Facing Camera



- Use plastic tweezers to carefully detach the front-facing camera from the motherboard.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-28 09:32:08 AM.